




INSTRUCTIONS FOR THE ASSEMBLY AND INSTALLATION

WARNING: Please throw off the plastic jackets before assembling.




Step 1 : After unfolding the changer body; begin assembly by inserting the base board.




Step 2 : Connect the tubes of two short sides by depressing the *Locking Button* and pushing inward.

Warning : Make sure that all of the tubes are firmly clicked and locked before using the changer. Injury could result if the tubes are not correctly assembled.



Step 3 : Installation of the changer: Your changer can be installed on either end of your playard. Begin by simply clipping the *Slotted Clips* over the fabric covered upper frame tube at the one end of the playard. After you have done this, clip the four *Base Clips* downward on both sides of the playard.



Step 4 : When not in use, your changer station can easily be put into its storage position by simply unclipping the *Base Clips* from the playard's fabric covered upper side tubes and swing the changer station to the outside of the playard.

WARNINGS :

FALL HAZARD-To prevent death or serious injury

- Always stay within arm's reach of your child when using the changing table. Never leave child unattended.
- The changing table is designed for use only with this the playard. Do not use on the floor, bed, counter or other surfaces. Before each use make sure the changing table is properly secured to the playard by pushing down firmly in the middle of the changing table.
- Do not use changing table as a sleeping or play area.
- Weight limit for the changing table is 25 lbs(11kg). Do not use the changing table as extra storage. Always remove the changing table when your child is in the playard.
- Do not use changing table if it is damaged or broken.

PLAYARD/BABY BED INSTRUCTIONS

BEFORE ASSEMBLING THIS PLAYARD AND UNDERSTAND THE INSTRUCTIONS. INCORRECT ASSEMBLY MAY MAKE THE PLAYARD UNSAFE.

DO NOT USE THIS PLAYARD IF ANY PART IS BROKEN, TORN OR MISSING. KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE

WARNINGS

Never leave children unattended.

Do not leave anything in the playard such as toys that provide a foothold to enable the child to climb out of the playard.

Do not use the playard near naked heat sources, bar heaters, open fires, or exposed flames.

Keep the playard clear of trailing cables and hanging cords.

Keep medication, and small items that a child could choke on away from the playard.

The thickness of the mattress has been specified to ensure that the distance from the top of the mattress to the top of the lowest side or end will always be at least 500 mm. This will reduce the risk of children falling out of the playard.

Portable playard with padded rims should not be used if the covering material has been torn or bitten through.

To prevent falls the bassinet (if supplied) should not be used once a child can sit up.

Before using the playard please check and ensure all top rails are locked securely

This playard is designed for use with children who cannot climb out of the playard, weigh less than 14 kgs, and who are less than 86 cm tall.

The bassinet (if supplied) is designed for use with children who cannot sit up unaided and are not heavier than 9 kgs.

The maximum weight of the child to be placed on the change table (if supplied) must not exceed 9 kgs.

Do not place more than one child in the playard or bassinet at the same time.

Do not try and move the playard while a child is in it.

Do not leave the playard outdoors exposed to direct sunlight.

Keep your fingers clear from corner joints and any moving parts when opening or folding the playard.

This product is not intended for commercial use.

Maximum capacity:15kgs.

Keep away from fire!


Parts Details

Photos are for reference only



Assemble Baby Playpen

1. Take playpen out of carry bag. (as pic1)
2. Take off Velcro at mattress padding, then take out the playpen. (as pic2)



3. Separate the 4pcs plastic parts top corner at the upper position of playpen to the largest distance, and try to gather the plastic parts under playpen. (as pic3)

4. Lift up the steel tube on 3 rails among 4pcs plastic parts top corner separately, to lock the folding mechanism of different steel tubes. (as pic3)
ATTENTION: Make sure the central locking mechanism to upper level, otherwise the locking mechanism among steel tubes unable to lock.


WARNING: Before using playpen, make sure the folding mechanism among long rails and short rail been locked completely otherwise could hurt childrens.

5. Press down the central locking mechanism until lock it completely 4pcs plastic parts support under playpen been separated automatically, playpen been unfolded completely (as pic5-1)


Lift the central plastic on the unfold rail and rotate half a circle to lock it. (as pic5-1)

ATTENTION: Unlock Velcro of fabric cap above the central locking mechanism to open fabric cover, try to pull red handle of the locking mechanism to make sure if it been locked completely. The button of locking mechanism should spring out at this moment, the button level should more higher than the central locking mechanism.


Please make sure all folding mechanism at long rails and short rails been locked completely




6. Close the fabric cap of the second lock, by attaching the Velcro. (as pic 6)
 7. Pls insert the tube through on another side hole under the bassinet when the spring is POP-UP is ok, another tube is same assembling (as show 7-1 pic), then put the hooks on armrest (as show 7-2/3 pic)




8. pls attention: pls make sure keep open the bassinet on can be up and down side (as show 8-1), then put all buckle on playpen (as show 8-2)



9. put the mattress within playpen, the soft side is upward (as show 9-1)
 Put the Velcro under the mattress through the holes in the upper bassinet fabric cover, which position is below the Velcro belt. (as picture 9-2)
 Velcro will be together on backside to fasten the mattress. (as picture 9-3)




10. Adjusted the position of the second layer: Turn on the both side of buckle (as pic 10-2), turn upwards middle of rail plastic and release the folding lock position (as pic 10-1), meanwhile press two buttons of below the two corner and put down and it has three level (as pic 10-3).



11. Put the buckle through the hole of loop on the playpens (as pic 11-1), after insert the buckle connect another buckle completely (as pic 11-2). another side same assembling.

Adjusted the belt middle of buckle and fix with Mama's bed.(as pic 11-3)



WHERE WHEELS AND BRAKES ARE FITTED




Before placing your child in the playard, apply the brakes and ensure that the wheels are locked

TO FOLD THE PLAYARD

12.Remove the mattress and set it aside.


13.Lift the flap of the locking mechanism by releasing the velcro fastener.

14.Push the button located in the center of the locking mechanism down.




15.Lift the handle of the locking mechanism up as high as possible.

16. There have 3pcs folding mechanism at the connection of long rails and short rail, hold up button to release the locking mechanism among steel tubes, Then turn over the lock mechanism of up and down side rail upwards to the release position (same as pic 16)





Attention: There are three buttons inside fabric covers, please hold the buttons tightly against fabric cover directly, make sure the second locking has been adjusted to image 4 position, then you can hold the button very tightly and press down the knots. Please don't use too much force to press the knots, please repeat steps 15 and steps 16 if the knots have not been released.





17. Fold the 4 plastic parts at the playpen's bottom side, making it at image 17 status (pic 17).

18. Please use the mattress to strap accessories and the playpen's body, then fix it by velcros, put it into carry bag and zip it up by zipper, then you can take the playpen to travel now (pic 18).



19. The images will be shown by the unacceptable beds and mattress (pic 19)

Acceptable bed in line:
Mattress, box spring & frame aligned (pic 19-1)



UNACCEPTABLE BED.
MATTRESS, BOX SPRING & FRAME NOT IN LINE

Maintenance

Wash the fabric cover of playpen's body and double layer bassinet and mattress, please rinse it by brush, then clean out all water, put it under shadow, let it dry.

For the very dirty position, please dilute detergent, then use detergent to rinse it, clean out the detergent thoroughly.

Wipe out the dusts gently, then clean the playpen's body with damp clothes, after that, erase the water by dry clothes.

The playpen's body will become black or obsolete if you did not erase the water.

Do not use bleacher. Put the cushion in the dark place to dry in the shade. Do not use dryer to dry it.

Do not let your playpen in direct sunlight. Otherwise, the plastic and fabric parts will fade.

If any damages or broken at mattress or beds, please stop using it, then contact with client service department immediately.

Due to the continuous improvement of products, design and specifications are subject to change without notice.

The pictures in instructions are just for reference.

They can not represent the actual product.